

## **FLOAT 3 SERIES**

## FRONT SUSPENSION SET-UP GUIDE

## EVOL UP ARROW ★ INDICATES CHASSIS MOUNT EVOL DOWN ARROW ▼ INDICATES A-ARM MOUNT



**FLOAT 3 EVOL QS3-R** 

Torque all fasteners to manufacturers specifications.

For track shocks, see specific kit install supplement sheet.



KIT PART NUMBER & DESCRIPTION	MAKE	LENGTH	TRAVEL	SAG SHOCK LENGTH	MOUNTED EVOL POSITION	MAIN PRESSURE	EVOL PRESSURE
850-21-252 Kit: Burandt Signature Series AM, POL, Pro-RMK React, Ski [15.91, 5.20] Float 3 EVOL QS3-QSR LW	Polaris	15.9	5.2	14.4	DOWN	70	130
850-21-259 Kit: FOX Factory AM, BRP, Summit RAS 3, Ski [17.59, 5.80] Float 3 EVOL QS3-QSR LW	BRP	17.6	5.8	15.9	DOWN	70	120
850-21-262 Kit: Fox Factory AM, POL, Pro-RMK React, Ski [15.91, 5.20] Float 3 EVOL QS3-QSR LW	Polaris	15.9	5.2	14.4	DOWN	70	130

## ALL SHOCKS SHIPPED PRESET TO FACTORY SETTINGS SET AT 70°F.

It is recommended that you check air pressure on initial setup before riding. Pressures should read 5-10 psi lower than Factory Settings. This is caused by the air in the shock filling the pump.

NOTE: ALWAYS SET EVOL CHAMBER AIR PRESSURE BEFORE SETTING MAIN CHAMBER AIR PRESSURE WITH NO WEIGHT ON THE FRONT END.

Technical Support: FOX Midwest Service Center at 1.831.740.4619 email to: psservicemw@ridefox.com

