



# ZERO SERIES

## FRONT SUSPENSION SET-UP GUIDE



**RESERVOIR ↑**

**ZERO QS3-R**

Install shock absorber with the proper orientation of the reservoir, body end of shock absorbers should be mounted to the chassis. This allows for less un-sprung weight. Torque all fasteners to manufacturers specifications.



---

KIT PART NUMBER & DESCRIPTION	MAKE	LENGTH	TRAVEL	SAG SHOCK LENGTH	INSTALLED SPRING LENGTH	SPRING RATE
<b>850-02-027</b> <b>Kit:</b> Burandt Signature Series AM, POL, Pro-RMK React, Ski [15.95, 5.35] 1.5 Zero QS3 LW	Polaris	16.0	5.6	14.3	10.3	95
<b>850-02-029</b> <b>Kit:</b> FOX Factory AM, BRP, Summit RAS 3, Ski [17.61, 5.93] 1.5 Zero QS3-QSR LW	BRP	17.6	5.9	15.8	10.4	100
<b>850-02-033</b> <b>Kit:</b> Fox Factory AM, POL, Pro-RMK React, Ski [15.92, 5.31] 1.5 Zero QS3-QSR LW	Polaris	15.9	5.3	14.3	10.3	95
<b>850-02-036</b> <b>Kit:</b> Fox Factory AM, AC, MCAT, Ski [16.41, 5.03] 1.5 Zero QS3-QSR LW	Arctic Cat	16.4	5.0	14.9	10.4	110